SHIDU

追梦者

音乐路上 尊享音响

DREAM CATCHER AUDIO USER MANUAL

使用说明

本机内置A品超动力电池，本厂产品录音电池采用5年

深圳市十度数码科技有限公司
Shenzhen SHIDU digital Co.,Ltd.
Tel:+86 - 755 - 21635868 Hotline:4008 939 488
Add:深圳市宝安区新桥街道大业路花冠A栋十度科技园
Building A8, Zone 2, Xinhe Xinxing Industrial Park, Baoan District, Shenzhen, China

执行标准：GB8898--2011;GB17625.1-2012;GB/T13837.2012

本说明书内容如有变动，恕不另行通知。本公司保留对本说明书内容的最终解释权。如对本说明书内容有疑问，请与本公司联系。本公司对因不当使用本产品而造成的损失概不负责。本说明书中的图片仅供参考，实际产品外观以实物为准。

十度原声 天籁之音

SOUND OF CHANGE
让改变 发声

尊敬的用户：

您好！
欢迎您使用SHIDU十度数码产品！
SHIDU十度数码产品通过高科技的品质和优质的服务进入您的工作和生活，您一旦拥有，就会真切感受到它的卓越性能和优良品质，让您时刻都能享受到生活的轻松愉快。为了更让您更好的发挥十度数码的精工品质，请您在使用本产品前，认真阅读本说明书，和用不断之处，您可向本公司客服查询。

无损保声明：

本手册中的内容，除非适用法律要求，十度数码科技对本手册中的所有内容不提供任何明示或暗示的保证，包括但不限于内容的适用性、十度数码科技在任何情况下，都不对因使用本手册和其内容而产生的任何特殊的、附带的、间接的、或者性质的损害进行赔偿，也不对任何利润、数据、商誉或可预期的损失进行赔偿。

进出口管制：

若贵将此产品手册中描述的产品出口、再出口或者进口，您应遵守适用的进出口管制法律法规。

安全警告：

01.请您将产品及配件置放大源或任何过热的环境中。
02.请您将产品及配件接触水及雷气，不要在靠近水的地方使用本设备，也不要将产品浸入任何液体中，避免产品及软件受到水浸或水泡。
03.请您自行打开或任意拆解，维修或组装，如果电池更换不当会有爆炸危险，严禁用电池投入火、水中或高压环境中的所有事。
04.产品自动中断电源及配备 (DC 18V/1.66A) 用电时使用，充电电后可方便的通过拔掉电源及配备插头来开电和电源。
05.当用户发现不合格关产品时，请用产品 "电源开关" 关闭（参见产品操作示意图），避免电池电量的流失。
06.当禁止使用充电设备或设备的使用会引起电子设备的干扰与安全隐患时，请关闭产品。
07.应禁思易爆区域，请关闭本产品，并遵守相关标示说明，以免引起爆炸或火灾。
易燃易爆区域包括但不限于：加油站、易燃或化工制品储运及存储设施，有爆炸危险标志的区域，有 "关闭双向无线电设备" 标志的区域。
08.乘坐飞机时，请遵守航空公司有关规定和条件，在飞机起飞前关闭本产品，以免造成安全隐患。
09.电源线不能被挤压，拉扯、弯曲、打结、易触摸物或被人踩踏，以防止电源线的绝缘层被损坏导致触电。
10.如机器发生冒烟或其他异常现象，请迅速拔出电源插头，避免引起意外事故，并联系当地经销商进行维修。
11.为保证通用产品质量予空矿的区域充电，远离可燃物，以免引起火灾。
12.仅适用于非热带气候条件下安全使用，仅适用于海拔2000米以下地区安全使用。

产品特性：

01.本产品可与个人电脑、DVD、VCD、CD、LD、TC、MP3、吉他、电子鼓等任何有音频输出的装置连接使用。
02.卡拉OK声卡音频，120W功放喇，支持手提。
03.配置DOV 8寸低音喇叭，3寸中高音喇叭，20W*2。
04.DC 18V 1000mAh 5C 4.5A动力电池，续航时间1-3小时。
05.配备5.1独立音频输入接口，配备独立音频输入，输出，蓝牙接口，直播，内录，立体声混输入。
06.支持TF卡，U盘播放功能。
07.选择采用3.4寸无线麦克风，高灵敏度动圈咪芯，CNC高精密铝合金装饰件。
08.支持自我调音。

面板功能说明：

产品（音箱）功能面板说明



01.电源开关：长按 "开关键" 键3秒开机语音提示后，电源绿色指示灯亮表示正常开机，再次长按关闭3秒电源绿色指示灯熄灭表示已关机。
02.USB接口（仅限音频传输功能U盘）
03.TF卡接口 04.蓝牙音对 05.直播输入口 06.监听输出口
07.直播接口：将机器通过直播线与手机连接，即可打开手机直播APP软件进行直播操作。
08.内录

09.蓝牙按开：在蓝牙模式下长按 "蓝牙按开" 为解开当前蓝牙，在其他模式下短按 "蓝牙按开" 为一键蓝牙。
10.上一曲 11.播放/暂停 12.下一曲
13.模式键：短按此按键可进行菜单选择，用来切换各种输入模式，蓝牙模式，U盘播放，TF卡播放，U卡模式，在音乐播放模式长按 "模式/循环" 键3秒提示单曲循环为单曲循环，再次长按 "模式/循环" 键3秒提示全部循环为全部循环。
14.DC 18V输入口：本音箱设备充电输入口，请使用原厂标配充电器为本机充电。
15.调频接口：本机支持有线调频输入（标配不含有线调频）。
16.话筒输入口 17.乐器输入口 18.电池指示灯
19.音效/录音旋钮：可调节音效乐器旋钮，使音效与播放更兼容。
20.音效/录音键：可调节乐器/音效/播放声音大小。
21.音乐音量：可调节音乐播放声音大小。
22.音乐低音：可调节音乐播放低音，使音乐更动听。
23.音乐高音：可调节音乐播放高音，使音乐更动听。
24.麦克风音量：可调节话筒音量大小，使话筒声音合适。
25.麦克风低音：可调节话筒的音质低音效果。
26.麦克风高音：可调节话筒的音质高音效果。
27.混响调节：可调节话筒混响，使话筒效果更佳。
28.延迟：可调节话筒延迟，使话筒效果更佳。

音乐播放功能说明：

01.本机U盘、TF卡接口，支持前端前用，支持MP3、WAV、WMA、FLAC和APE等主格式播放，解码音质表现优先保真立体音设计给你全新的音乐体验。
02.▶II 播放/暂停按键，在播放状态时，短按此键可暂停播放歌曲，再次短按此键即可继续播放。
03.⏮ 上一曲/⏭下一曲按键，在音乐播放模式下，短按此键可以进行播放列表上下选取。

蓝牙功能操作说明：

第一步：开机，按 " 模式 / 循环 " 键切换至蓝牙模式（当主机提示 " 蓝牙已准备好，正在等待配对 "，显示灯蓝灯闪烁时为蓝牙模式。
第二步：打开手机，进入手机的 " 设置 " 菜单，找到蓝牙功能选项，打开手机的蓝牙功能，点 " 扫描 " 按钮，待搜索到 " A8 " 点击 " A8 " 连接即可，同时主机会提示蓝牙已配对。
第三步：配对成功后，即可通过 A8 播放手机里存储好、访问的音频，歌曲播放等，同时也可与无线麦克风配合使用，实现合唱歌曲。通过手机 K 歌软件实现同步 K 歌等功能。

充电功能操作说明：

充电时，请先将主机电源开关关闭，关机状态充电。请用原厂标配电源适配器接上220V伏特进行充电，充电时间约5小时可充满，充满电后应拔掉电源适配器插头断开电源电路。
○在工作状态时，绿色电源指示灯会或红色的表示还有20%的电量，当红色指示灯闪烁的表示电量不足，请及时充电。
○充电时红色电源灯闪烁，充满电后红色电源灯长亮，充满电后电池量继续充电1~2小时，这样能延长电池使用时间。
○若电池欠压，请在4小时内把电池充满，电池长时间放置不工作会损保护电池寿命，否则会造成电池损坏，当主机电量发生异常自动关机后请将主机放置在空旷的区域远离可燃物品充电。

充电示意图

UHF无线麦克风指示灯说明：

01.UHF无线话筒开/关机：

长按 " 功 " 键开机，屏幕显示默认频点值，打开主机后可实现无UHF无线扩展，在开机状态下，长按 " 功 " 电源开关键，屏幕相关显示话筒已关机，在使用过程中短按 "+" 为切换加频点，长按 "+" 为加快增，短按 "-" 为切换减频点，长按 "-" 为减慢增。
（注：话筒1分钟后会屏保，短按任意一个键就可以点亮屏幕）

02.UHF无线话筒手动配对：

（此操作方法适用于话筒无声时手动配对）
a.打开主机按 " 模式/循环 " 键切换至UHF模式，再长按 " 模式/循环 " 键3秒，主机就进入UHF等待配对，显示当前的频点，快速短按开机键3次当前模式闪烁，表示第二支无线话筒与机器手动配对成功，表示第二支无线话筒与机器手动配对成功，即可实现双无线扩展。

03.UHF无线话筒电池说明：

在使用过程中，手持式UHF无线麦克风显示电量提示符为 " 量 " 满格时，表示电量充足，当显示电量提示符为 " 口 " 空格时，表示电池电量，请及时更换电池。
注：正确打开电池盖，装入电池，注意电池的正负极不要装反。

遥控器功能说明：

01.自定常情况下，遥控器在遥控接收窗前的2米，30度范围内使用。
02.操作遥控器时，将遥控器对准机器的遥控窗口，遥控器与机器之间不应有阻碍物。
03.如果遥控器被遮挡或于遥控接收窗内有物体时红黑遥控器不能失效，在此情况下，请将机器移开，以避免连接断开。
04.遥控器供电池型号请使用，切勿把普通的锂电池混充使用。
注：说明书为示意图，具体以实物为准。

技术规格：

额定功率：≤120W
信噪比：≥80dB
频率响应：30Hz~20KHz
输入阻抗：DC 18V==1.66A
以上规格为样机技术规格，仅供参考。

符合人员对低压电器产品的保护要求认证合格证书。

无线电干扰标准产品

无线电干扰标准 2002 年
以下地区安全使用。

故障自我检查：

用户在使用本机过程中，如发现有问题，请按下面的故障排检查表进一检查，仍然不能解决问题，请找本公司在当地的经销商携带或寄回本公司的售后服务组咨询，故障维修请具体说下面这个表格：

故障现象	可能原因	处置方法
灯开电源关但机声音	a.主机没电。 b.连接有问题或不良。 c.音量调节在了最小位置。	a.给主机充电或检查显示屏是否点亮正常开机。 b.检查连接线是否接入信号，以及连接可靠性。
声音失真	a.音量调节过大。 b.音响可能损坏。	a.将主音量调小。 b.检查音响是否损坏，若损坏，请联系维修。
播放无声	a.U盘歌曲格式不对。 b.操作不当出现按键失误。 c.U盘/TF卡没有插好。	a.格式化U盘/TF卡，重新拷贝歌曲文件，根据操作说明操作7调试。 b.开机重启试试。 c.插好U盘/TF卡。
充电后仅指示灯亮但没有电量显示	a.电池损坏。 b.电池连接松动。 c.未将电量充足。	a.更换同型号的电池。 b.将主机与充电器连接好。 c.将电量充足后再使用。

Welcome to use SHIDU digital speaker, A8 is a multifunction portable speaker with Bluetooth and voice amplifier functions, and it can also support Guitar and Instrument input, Please enjoy it after reading the user manual.

Technical Parameters:

Product model:	A8	S/N ratio:	≥80dB
Rated power:	4120W	Frequency response:	30Hz~20KHz
Sensitivity:	>49±3dB	Recharging voltage:	DC 18V/1.66A
Music-use time:	12-13hours	Charging time:	6-8hours

Structure Instruction:



1.Power on/off: Long press it for 3 seconds, the green battery indicator light on means power on, Long press it again for 3 seconds, the green battery indicator light out means power off.
2.USB slot: Support USB flash drive, maximum up to 32G (MP3 WAV WMA)(Reading the data of USB flash drive only).
3.TF card slot: Support TF card, maximum up to 32G (MP3 WAV WMA).

4.Bluetooth Indicator light
5.Audio input
6.Monitor jack （Reference function description for details）
7.Live broadcast jack（Reference function description for details）
8.Direct recording jack
9.Bluetooth/Disconnect: Short press this in any mode to enter into Bluetooth waiting for pairing status, long press this button in Bluetooth mode to disconnect.
10.Previous: Short press to select previous audio file,
11.Play/Pause: In audio playing mode, press it to pause; press it again to play.
12.Next: Short press to select next audio file,
13.Mode/Loop: Short press it to select the following modes: AUX mode, Bluetooth mode, USB flash drive mode, TF card mode, UHF mode. When play music on TF card/USB flash drive, long press it for 3 seconds to switch to single song repeat, long press it again to switch back to all repeat.
14.DC 18V Charging port: Charging port, please using original adapter to charge.
15.MIC: Support wired Mic (not included),
16.Guitar input
17.Instrument input
18.Battery indicator light
19.Guitar/Instrument ECHO control
20.Guitar/Instrument volume control
21.Music volume control
22.Music bass control
23.Music treble control
24.Microphone volume control
25.Microphone bass control
26.Microphone treble control
27.Microphone ECHO control
28.Microphone DELAY control

Playing from TF card/USB flash drive:

The speaker will automatically play the music file after insert TF card/USB flash drive, and the previous song and the next song can be selected by short press the " ⏮ " / " ⏭ " button.

Bluetooth Function:

Please pair with your Bluetooth device as follows:
1,Turn on the amplifier and press "Mode/Loop" key to switch to Bluetooth mode, A voice will prompt "Bluetooth is waiting for connection" and the Bluetooth indicator light will flash,
2,From your mobile setting, turn on the Bluetooth function, Then search for "A8" and connect, Bluetooth pairing is completed with a voice prompt "Bluetooth is connected",
When playing music, please keep the amplifier close to the Bluetooth-enable device to maintain a stable connection.

Monitor Function:

1,Plug in your headphones and you can hear the music the machine is playing, including sound of the microphone, to get a more realistic feeling for what you're recording live, At the same time, the machine still has sound,
2,You can mute it with the remote control, and the machine will have no sound, only the earphones have sound.

Live Broadcast Function:

This feature allows you to achieve better recording effects during live broadcasts,
When you use our machine to play music and use a microphone to record a live broadcast, use the red cable in the standard configuration. One end is plugged into the headphone jack of your mobile phone, and the other end is plugged into the live broadcast jack. This red line is passed from the machine to achieve better recording sound.

Direct Recording Function:

This function allows you to achieve better recording effects for Karaoke APP,
When you are using our machine to sing a song via Karaoke APP, use the red cable to recording the sound directly, One end is plugged into the headphone jack of your mobile phone, and the other end is plugged into the direct recording jack.

Charging the device:

1,Please power off speaker when charging, please use the standard adapter, the other end connects with the power supply AC 220V to charge, Please unplug the adapter timely after fully charged (the charging time is normally 6-8 hours),
2,Battery status: The green battery indicator light turns red color means that 20% battery left, When the red battery indicator light flash, the unit needs recharging,
3,The red indicator light is on all the time when charging, and it will go out after fully charged,
4,Please recharge the battery within 48 hours if the voltage is too low, Out of power is bad to the battery.

Wireless Microphone Operation:



1.Switch ON / OFF:

1,Long press " ⏻ " to switch on and there will be UHF frequency point by default shows on the screen, Turn on the speaker, and then the speaker and microphone will connect automatical, Long press " ⏻ " again to switch off and the screen will go out,
2,Short press "+" or "-" to change frequency point from 700MHz-740MHz,
3,Long press "+" to increase mic volume while long press "-" to decrease mic volume, (Volume level on the microphone from 0-20.)

2.Pair the UHF Wireless MIC Manually:

（This operation only suits for no sound from the MIC）
Step 1: Switch on the speaker, short press "Mode/Loop" key to switch to UHF mode, then long press "Mode/Loop" key 3 seconds to enter into UHF wireless pairing status with voice prompt "UHF is waiting for connection",
Step 2: Switch on the UHF wireless MIC，short press "+" or "-" to change frequency point from 700MHz-740MHz, Quick press the " ⏻ " 3 times and then current frequency stop flashing means pairing is successful, Please manually pairing the second microphone in the same way. Then it's possible to amplify voice with two wireless MIC.

3.Battery Indication of UHF Wireless MIC:

In working status, it has sufficient battery power with " 量 " indication showed on the screen; it's low battery when screen shows " 口 " indication, pls replace AA battery "2 timely.
Note: Please twist-off the battery cover and put the batteries properly. (Please mind the positive & negative anode)

Remote function:

1.Normally,the remote control should be in front of the receiving window and within the scope of 6M & 30°.
2,Please point the remote control toward the receiving window and avoid the obstacle,
3,Please avoid the strong light.
4,Please don't use old & new battery at the same time,
Note: Please refer to the real product.

Trouble Shooting:

1.Switch on the speaker but no sound.
1,1.No audio input: Please use another better audio files;
1,2.Haven't turned on the volume: Please adjust the volume properly;
1,3.No power of speaker:Charge the speaker to see whether screen has been lightened.

2.With sound distortion.
2,1.The volume is too high: Please turn down the volume properly;
2,2.The speaker is broken: Please contact us for maintenance.

3.No sound with MP3 playing.
3,1.The audios' format in USB flash drive or TF card is wrong: Please turn the format to MP3;
3,2.Chaotic procedure with wrong operation: Please restart the speaker;
3,3.Haven't inserted the USB flash drive / TF card properly: Please insert the USB / TF card properly.

4.Can only work several minutes after charged.
4,1.The battery is broken: Please change a new same battery;
4,2.The connecting cable of battery is loosened or disconnected: Please contact us for maintenance;
4,3.Hasn't full charged the speaker: Please full charge it before using.

SHIDU Guarantee:

100% SHIDU Guaranteed Product Satisfaction,
We promise 1 year warranty.
If you have any questions, please feel free to contact us, we will try our best to provide you the best service,
www.10shidu.com Email: info@10shidu.com