









# 十度P13MINI 说明书 128G双铜+风琴折 420\*100MM C.006.0120

 <p><b>SD-P13mini</b> 使用说明书 USER MANUAL</p>	<p><b>产品尺寸图</b> 音箱功能按键示意图</p>  <p><b>注意事项</b> 电池(电池包或组合电池)不得暴露在诸如日光、火烤或类似过热环境中,如果电池更换不当会有爆炸危险,只能用样类型或等效类型的电池来更换,本产品不配带电源适配器销售,消费者若使用电源适配器供电,则应购买配套使用获得CCC认证并满足标准要求的电源适配器。</p>	<p><b>产品示意图</b> 音箱功能按键示意图</p>   <p>1.开机/关机 2.下一曲/音量加 3.暂停/播放/接听/挂断 4.上一曲/音量减 5.AUX插口 6.TF卡插口 7.TPYE-C插口 8.USB插口</p>	<p><b>操作示意图</b> 音箱功能按键说明</p> <ol style="list-style-type: none"><li>1.开机/关机:短按模式切换;长按开机/关机;双击TWS配对断开。</li><li>2.下一曲/音量加:短按加音量;长按下一曲。</li><li>3.暂停/播放/接听/挂断:短按暂停/播放/接听/挂断;长按来电时拒接;双击灯光切换。</li><li>4.上一曲/音量减:短按减音量;长按上一曲。</li><li>5.AUX插口:长可插入直径3.5mm立体头的音频线外接音源。</li><li>6.TF卡插口:播放TF卡音乐/语音,最大支持32GB。</li><li>7.TPYE-C插口:TPYE-C充电线充电。</li><li>8.USB插口:播放U盘音乐/语音,最大支持32GB。</li></ol>	<p><b>产品参数</b></p> <table border="0"><tr><td>产品名称: SD-P13mini 便携式音箱</td><td>电池容量: 3.7V/1800mAh</td></tr><tr><td>产品型号: SD-P13mini</td><td>输入: DC 5V=1A</td></tr><tr><td>无线版本: 5.4</td><td>播放时间: 6小时</td></tr><tr><td>传输距离: ≥10M</td><td>待机时间: 100天</td></tr><tr><td>频 率: 85Hz-20Hz</td><td>充电时间: 3小时</td></tr><tr><td>信 噪 比: ≥75dB</td><td>产品净重: 325G</td></tr><tr><td>额定功率: 8W</td><td>产品尺寸: 92x93x44mm</td></tr><tr><td>驱动单元: 52mm</td><td></td></tr></table> <p><b>售后服务</b> 本产品有效保修期为自出售之日起一年内,在保修期限内正常使用和维护的情况下,机器本身机件材料及功能出现问题,发生故障,经查属实,本公司将免费提供维修服务。</p> <p><b>本产品的保修不适用于</b></p> <ul style="list-style-type: none"><li>A. 音箱已超出保修期;</li><li>B. 用户未按照说明指南要求,造成音箱线材折断,外壳破损;</li><li>C. 未经本公司授权自行拆装,修理,改动结构;</li><li>D. 无法提供保修卡及消费凭证;</li><li>E. 因自然灾害等不可抗力(如地震、火灾)原因造成的产品故障或损害</li></ul> <p>注:保修服务不含产品运输费用及不提供上门维修服务</p> <p>15.制造型号:SD-P13mini。</p>	产品名称: SD-P13mini 便携式音箱	电池容量: 3.7V/1800mAh	产品型号: SD-P13mini	输入: DC 5V=1A	无线版本: 5.4	播放时间: 6小时	传输距离: ≥10M	待机时间: 100天	频 率: 85Hz-20Hz	充电时间: 3小时	信 噪 比: ≥75dB	产品净重: 325G	额定功率: 8W	产品尺寸: 92x93x44mm	驱动单元: 52mm		<p><b>产品注意事项</b></p> <ol style="list-style-type: none"><li>1.为保证锂电池使用寿命,建议使用完再充电,频繁充电将加速电池芯片老化,长时间未使用时应每隔两个月充一次电;</li><li>2.因磁场性较强,不可将机器和银行卡等带磁性的东西放一起,以免造成失磁而带来不必要的麻烦;</li><li>3.本产品所有配件皆按本机工作需要设计,如需更换配件尽量使用本公司原装配件,以达到最佳工作状态;</li><li>4.本产品在充电和正常使用过程中可能会轻微变热,这属于正常现象;</li><li>5.请使用抗静电软布来清洁擦拭本产品,在清洁本产品时请先关闭电源开关,并断开所有外部连接。请勿用化学物质擦拭(如:酒精、苯等化学洗剂或有磨砂性的清洁擦拭剂);</li><li>6.请勿摔落、抛掷或者踩踏本产品,请勿擅自拆解本产品,否则不能享受本公司的免费保修服务;</li><li>7.符合“微功率短距离无线电发射设备目录和技术要求”的具体条款和使用场景,采用的天线类型和性能,控制、调整及开关等使用方法;</li><li>8.不得擅自改变使用场景或使用条件、扩大发射频率范围、加大发射功率(包括额外加装射频功率放大器),不得擅自更改为发射天线;</li><li>9.不得对其他合法的无线电台(站)产生有害干扰,也不得提出免受有害干扰保护;</li><li>10.应当承受辐射射频能量的工业、科学及医疗(ISM)应用设备的干扰或其他合法的无线电台(站)干扰;</li><li>11.如对其他合法的无线电台(站)产生有害干扰时,应立即停止使用,并采取措施消除干扰后方可继续使用;</li><li>12.在航空器内和依据法律法规、国家有关规定、标准划设的射电天文台、气象雷达站、卫星地球站(含测控、测距、接收、导航站)等军民用无线电台(站)、机场等的电磁环境保护区域内使用微功率设备,应当遵守电磁环境保护及相关行业主管部门的规定;</li><li>13.禁止在以机场跑道中心点为圆心、半径5000米的区域内使用各类模型遥控器</li><li>14.微功率设备使用时温度和电压的环境条件。</li><li>15.制造型号:SD-P13mini。</li></ol>	<p><b>产品保修卡</b></p> <p>购买产品时,请认真填写此卡,并予以妥善保存。</p> <p><b>用户档案</b></p> <table border="1"><tr><td>用户姓名</td><td></td></tr><tr><td>性别</td><td></td></tr><tr><td>通讯地址</td><td></td></tr><tr><td>邮编</td><td></td></tr><tr><td>联系电话</td><td></td></tr><tr><td>购买地点</td><td></td></tr><tr><td>购买日期</td><td></td></tr><tr><td>品名及规格</td><td></td></tr><tr><td>销售单号</td><td></td></tr><tr><td>机身编号</td><td></td></tr><tr><td>经销商签名</td><td></td></tr><tr><td>用户签名</td><td></td></tr></table> <p>中国制造</p> <p>经销商盖章处</p>	用户姓名		性别		通讯地址		邮编		联系电话		购买地点		购买日期		品名及规格		销售单号		机身编号		经销商签名		用户签名	
产品名称: SD-P13mini 便携式音箱	电池容量: 3.7V/1800mAh																																													
产品型号: SD-P13mini	输入: DC 5V=1A																																													
无线版本: 5.4	播放时间: 6小时																																													
传输距离: ≥10M	待机时间: 100天																																													
频 率: 85Hz-20Hz	充电时间: 3小时																																													
信 噪 比: ≥75dB	产品净重: 325G																																													
额定功率: 8W	产品尺寸: 92x93x44mm																																													
驱动单元: 52mm																																														
用户姓名																																														
性别																																														
通讯地址																																														
邮编																																														
联系电话																																														
购买地点																																														
购买日期																																														
品名及规格																																														
销售单号																																														
机身编号																																														
经销商签名																																														
用户签名																																														

 <p><b>SD-P13mini</b> PORTABLE SPEAKER USER MANUAL</p>	<p><b>Product Dimension Drawing</b> Speaker function button diagram</p>  <p><b>Precautions</b> Batteries (battery packs or combined batteries) shall not be exposed to such as sunlight, fire or similar overheating environment. If the battery is not replaced properly there will be a risk of explosion, so please replace it with the same type or equivalent type of battery. This product does not come with a power adapter, consumers should purchase a power adapter that is CCC certified and meets the standard requirements when changing it through a power adapter.</p>	<p><b>Product introduction</b> Speaker function button diagram</p>   <p>1.Power On/Off 2.Next Track/Volume Up 3.Pause/Play/Answer/Hang Up 4.Previous Track/Volume Down 5.AUX Port 6.TF Card Slot 7.TPYE-C Port 8.USB Port</p>	<p><b>Operation Guide</b> Speaker function button description</p> <ol style="list-style-type: none"><li>1. Power On/Off: Short press to switch modes; long press to power on/off; double-click to disconnect TWS pairing.</li><li>2. Next Track/Volume Up: Short press to increase the volume; long press for the next song.</li><li>3. Pause/Play/Answer/Hang Up: Short press to pause/play or answer/hang up calls; long press to reject incoming calls; double-click to switch lights.</li><li>4. Previous Track/Volume Down: Short press to decrease the volume; long press for the previous song.</li><li>5. AUX Port: It can insert an audio cable with a 3.5mm stereo plug to connect external audio sources.</li><li>6. TF Card Slot: Play music/voice from the TF card, supporting a maximum of 32GB.</li><li>7. TPYE-C Port: Charge with a USB-C charging cable.</li><li>8. USB Port: Play music/voice from a USB flash drive, supporting a maximum of 32GB.</li></ol>	<p><b>Product Parameters</b></p> <table border="0"><tr><td>Product name: SD-P13mini Portable Speaker</td><td>Battery capacity: 3.7V/1800mAh</td></tr><tr><td>Product model: SD-P13mini</td><td>Input: DC 5V=1A</td></tr><tr><td>Wireless version: 6.0</td><td>Play time: 6h</td></tr><tr><td>Transmission distance: ≥10M</td><td>Standby time: 100 days</td></tr><tr><td>Frequency response: 85Hz-20Hz</td><td>Charging time: 3h</td></tr><tr><td>SNR: ≥75dB</td><td>Net weight: 325G</td></tr><tr><td>Rated power: 8W</td><td>Product size: 92x93x44mm</td></tr><tr><td>Driver unit: 52mm</td><td></td></tr></table> <p><b>After-sales Service</b> This product is covered under warranty for a period of twelve months from the date of sale limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification, will be provided free repair.</p> <p><b>This warranty does not apply</b></p> <ul style="list-style-type: none"><li>A. To a product that is out of warranty;</li><li>B. To damage caused by operating the product outside the permitted or intended uses described by WK.</li><li>C. To a product that has been disassembled, repaired or refitted without the authorization of WK;</li><li>D. If warranty card and proof of purchase cannot be presented;</li><li>E. To damage caused by external causes and natural disasters, including earthquake, fire, etc.</li></ul> <p>Note: The warranty does not include product transport costs and does not provide on-site maintenance services.</p>	Product name: SD-P13mini Portable Speaker	Battery capacity: 3.7V/1800mAh	Product model: SD-P13mini	Input: DC 5V=1A	Wireless version: 6.0	Play time: 6h	Transmission distance: ≥10M	Standby time: 100 days	Frequency response: 85Hz-20Hz	Charging time: 3h	SNR: ≥75dB	Net weight: 325G	Rated power: 8W	Product size: 92x93x44mm	Driver unit: 52mm		<p><b>注意:</b> 本手册描述的产品及其附件的某些特征和功能,仅供参考。 十度数码科技保留随时修改本手册中任何信息的权利,无需进行任何提前通知且不承担任何责任。</p> <p><b>无担保声明:</b> 本手册中的内容,除非适用法律要求,十度数码科技对本手册中的所有内容不提供任何明示或暗示的保证。 在法律允许的范围内,十度数码科技在任何情况下,都不对因使用本手册相关内容而产生的任何特殊的、附带的、间接的、继发性的损害进行赔偿,也不对任何利润、数据、商誉或可预期的损失进行赔偿。</p> <p><b>进出口管制:</b> 若需将此产品手册中描述的产品出口、再出口、或者进口,您应遵守适用的进出口管制法律法规。</p>
Product name: SD-P13mini Portable Speaker	Battery capacity: 3.7V/1800mAh																				
Product model: SD-P13mini	Input: DC 5V=1A																				
Wireless version: 6.0	Play time: 6h																				
Transmission distance: ≥10M	Standby time: 100 days																				
Frequency response: 85Hz-20Hz	Charging time: 3h																				
SNR: ≥75dB	Net weight: 325G																				
Rated power: 8W	Product size: 92x93x44mm																				
Driver unit: 52mm																					